

To the owners

450Rally Two-wheeled motorcycle instruction manual

Third Version (March, 2023)

First of all, congratulations on your purchase of a new Kove motorcycle.

By choosing a Kove product, you have become a member of the Kove Motorcycle family.

The instruction manual introduces the main specifications, basic structure, adjustment methods and maintenance knowledge of the motorcycle. It will guide you to master the basic operation of the motorcycle as well as troubleshooting or reducing common faults, which will effectively guarantee the safety of driving, bring out the best performance of the bike, and improve the service life of the motorcycle.

This manual contains the basic configuration of the motorcycle, the content and pictures are for reference only, please refer to the real thing.

Due to the factory time, user requirements and design improvements, etc., may lead to differences between the actual bike and the manual content, we reserve the right to make changes at any time without further notice or obligation, so please understand the inconvenience caused.

The instruction manual is one of the necessary accessories for the motorcycle and should be attached to the motorbike when reselling it to another person.

The copyright of this manual belongs to the company, without the written consent of the company is not allowed to reprint, violators will be investigated.

To ensure your safety and increase your riding pleasure:

- ☐ Please read this instruction manual carefully
- ☐ Please follow all recommendations and procedures in the instruction manual
- ☐ Please pay more attention to the safety information written in the instruction manual and pasted on the motorcycle

Security precautions

Your safety and the safety of others is important, and riding this motorcycle safely is an important responsibility.

To help you make wise decisions about your safety, we have provided procedures and other information on the safety label and in the instruction manual that will alert you to potential hazards that could harm you or others.

Of course, it would be impractical for us to list all the dangers associated with motorcycle riding and maintenance, and you must make the correct judgment.

The addition of electrical equipment is prohibited because the battery used in this motorcycle is a lithium battery, which has a small capacity and may result in a loss of power if electrical equipment is added.

This motorcycle is equipped with a high-speed engine, and for your driving safety, it is recommended that you reduce violent driving.

You will see important safety information in various forms, including:

- Safety label on the body of the motorcycle;
- The safety message is preceded by a safety warning symbol  and one of the following three warnings: CAUTION, DANGER, WARNING.

The meanings of the three warning phrases are shown below:



-if you don't follow the instructions, you may be injured.



-if you don't follow the instructions, it will result in serious injury or death.



-if you don't follow the instructions, it will result in serious injury or death.

Additional important information is listed below the following headings:

Note -information to help you avoid damage to your motorcycle, other property or the environment.

Catalog

Motorcycle Safety 4

Operation Guide 13

Maintenance 28

Troubleshooting 63

Related Information 72

Technical Specs 82

Motorcycle Safety

This section contains important information for safe motorcycle riding, please read this section carefully.

Security Guide	5
Safety Precautions	8
Riding Precautions	9
Accessories and modifications	12
Loading Guide	12

Security Guide

To enhance the safety of your ride, please follow these guidelines:

- Perform all daily and routine checks specified in the operating instructions.
- Before refilling the fuel tank, turn off the engine and keep it away from sparks and open flames.
- Don't start the engine in a confined or semi-confined space because the exhaust gases contain carbon monoxide, a toxic gas that can be fatal.

Always wear a helmet

Helmets and protective clothing have been shown to significantly reduce the chance of injury to the head and other parts of the body, and to reduce the extent of injury. Therefore, always wear a certified motorcycle helmet and protective clothing when riding.

Before Riding

Make sure you are in good physical condition, focused, and have not been drinking or taking drugs. Wear a certified motorcycle helmet and protective clothing, keep your hands on the steering handlebars and your feet on the pedals, and lean your body when turning, even when the motorcycle is stopped.

Take the time to learn and practice

Even if you have ridden other motorcycles, practice driving this motorcycle in a safe area to become familiar with the operation and handling of this bike and to adapt to the size and weight.

Be aware of protection when riding a bike

Always be aware of the vehicles around you, don't assume that other drivers can see you, and always be prepared to apply emergency brakes or dodge detours.

Make yourself easily seen

Especially at night, wear bright reflective clothing to make yourself more visible, stop where other drivers can see you, turn on your signal before turning or changing lanes, and honk your horn to alert pedestrians when necessary.

Do not drink and ride

Alcohol and riding are never compatible. Never ride beyond your personal capacity or exceed the speed limit set by your bike; fatigue and negligence will impair your ability to make good judgments and drive safely.

Keep your motorcycle in safe condition

It is important to keep your motorcycle in good condition at all times; check your motorcycle before each ride and complete all recommended maintenance and repairs, **do not modify your motorcycle or add accessories that would affect safety, and strictly prohibit overloading.**

Dealing with unexpected events

Your personal safety is your first priority. If you or anyone else is injured, you should first carefully assess the severity of the injury and determine whether it is safe to continue riding. If necessary, call for emergency assistance. When other people or motorcycles are involved in a collision, you should also follow the laws and regulations that apply.

If you decide to continue riding, first turn the ignition switch to the "⊗" (off) position, then assess the condition of the motorcycle, check for oil leaks, check that key nuts and bolts are tight, and check the steering handle, steering column, brakes and wheels, and ride slowly and carefully.

Your motorcycle may have sustained damage that is not immediately apparent, so please take it to an authorized Kove repair shop or a qualified repair store for a thorough inspection as soon as possible.

Carbon monoxide hazards

The exhaust contains toxic carbon monoxide, a colorless and odorless gas that can cause unconsciousness and may even be fatal if inhaled.

If you start your engine in a confined or semi-confined space, the air you inhale may contain dangerous amounts of carbon monoxide. Never start the engine in a garage or other confined space.



WARNING

- Running a motorcycle engine in a confined or semi-confined space can lead to a rapid build-up of toxic carbon monoxide gas.
- Inhalation of this colorless and odorless gas can cause rapid loss of consciousness and death.
- Start the motorcycle engine only in a well-ventilated outdoor area.

Safety Precautions

- Drive carefully, always keep your hands on the steering handle and your feet on the pedals.
- Always pay attention to driving safety, try to stay away from all kinds of motorcycles, avoid pedestrians and slow down.
- Observe basic driving rules and drive on the right.
- Never carry a passenger. Your motorcycle is designed for single riders, and carrying a passenger may cause an accident in which you and others may be injured.

Protective clothing

Make sure you are wearing a certified motorcycle helmet, goggles and visible protective clothing, and ride carefully according to weather and road conditions

Helmets

Certified by safety standards, eye-catching and sized to fit your head

- Must be secure and comfortable and held in place with a chin strap.
- Face shield or other certified goggles that do not obstruct vision.

Gloves

High abrasion resistant full finger leather gloves.

Boots or riding shoes

Sturdy and slip-resistant boots that protect the ankle.

Clothing

Eye-catching long-sleeved shirt and durable pants(or protective suit) with protective effect for riding.



- Not wearing a helmet increases the chances of serious injury or death in an accident.
- Make sure you always wear certified helmets and protective clothing.

Riding Precautions

Break in period

Follow these guidelines during the first 500 miles of driving to ensure reliability and performance later in the motorcycle's life

- Avoid full throttle starts or rapid acceleration.
- Avoid emergency braking and rapid downshifting.
- Ride with caution.

Brake

Follow these guidelines:

- Avoid excessive emergency braking and downshifting.
 - ▶ Sudden braking can reduce the stability of your motorcycle.
 - ▶ Slow down before you turn, otherwise you will risk slipping.
- Always ride carefully on slippery roads
 - ▶ Tires on such surfaces are more likely to skid and require longer braking distances.
- Avoid continuous braking
 - ▶ When going downhill on long and steep slopes, repeated braking will cause the brakes to seriously overheat and affect the braking effect, so the brakes should be used intermittently to slow down with the help of engine braking.
 - ▶ Using both front and rear brakes can achieve complete braking effect.

Anti-lock Braking System (ABS)

This model is equipped with an ABS system, which prevents tire lock-up during emergency braking.

- The ABS does not work when the bike speed is below 10 km/h.
- When braking, it is normal that the brake handle or rear brake pedal may bounce gently after the ABS intervenes.
- Always use the recommended tires to ensure that the ABS will operate correctly.

Engine Brake

When you release the throttle, the engine brake will help the motorcycle slow down. If you want to slow down even more, you can downshift to a lower gear; when going downhill on long and steep slopes, you should slow down with the help of the engine brake and use the brake intermittently.

Humid and rainy environment

In wet and rainy conditions, the road will be slippery and wet brakes will reduce braking efficiency, so be extra careful when braking. If the brakes are wet, you can intermittently and repeatedly brake while driving at low speeds, which helps to dry the brakes quickly.

Parking

- Park on a firm, level surface.
- If you must park on a slightly sloped or loose surface, make sure it is firmly parked and that the motorcycle cannot move or tip over.
- Make sure that hot parts do not come into contact with flammable materials.

- Do not touch the engine, muffler, brakes and other hot parts until they have cooled down.
- To avoid the possibility of theft, always lock the steering handlebars and remove the keys before leaving the motorcycle unattended.

Parking with side stand

1. Turn off the engine.
2. Lower the side stand.
3. Slowly lean the motorcycle to the left until its weight is concentrated on the side stand.
4. Turn the steering handle completely to the left.
 - ▶ Turning the steering handle to the right will reduce stability and may cause the motorcycle to fall over.
5. Turn the ignition switch to the "  " (locked) position and remove the key.

Refueling/Brake Fluid and Fuel Guide

Follow these guidelines to protect your engine and catalytic converter:

- Use only unleaded gasoline.
- High octane gasoline is recommended; use of lower octane gasoline will reduce engine performance.
- Ethanol gasoline is not recommended; using ethanol gasoline can reduce engine performance.
- Do not use spoiled or contaminated gasoline, or oil-gasoline mixtures.
- Prevent dirt and water from entering the fuel tank.
- Brake fluid has a corrosive effect. When adding it, be sure to avoid splashing in the eyes, adhering to the skin and avoiding contact with non-metallic materials of the vehicle.

Accessories and modifications

We strongly recommend that you do not add accessories to your motorcycle other than those designed specifically for your motorcycle by Kove, and do not modify the original design of your motorcycle, as doing so may render it unsafe. Unauthorized modifications to your motorcycle may also void your warranty and render your motorcycle illegal to drive on public roads and highways. When you decide to add accessories to your motorcycle, first determine which modifications are safe and legal.

It is prohibited to attach a trailer or add a straddle bucket to your motorcycle; it is prohibited to modify or add other equipment at the engine mounting point. Your motorcycle is not designed for these accessories and their use can seriously damage the handling and safety of the motorcycle.



WARNING

- Improper accessories or modifications may cause safety accidents in which you may be seriously injured or even endanger your life.
- Please follow all instructions in the instruction manual for accessories and modifications.

Loading Guide

- Carrying extra weight can affect the handling, braking and stability of your motorcycle. Please be sure to maintain a safe speed when riding with a heavy load.
- Please stay within the specified loading limits, the maximum payload for the entire bike is 75kg, do not overload.
- Secure all luggage and place it evenly and smoothly near the center of the motorcycle.
- Do not place items at the lights or muffler.



WARNING

- Overloading or improper loading can lead to accidents and serious injury or death.
- Please follow the loading instructions in the instruction manual for loading.

Operation Guide

This section contains important information on the operation of motorcycle use, please read this section carefully.

Parts location diagram..... 14

Instrumentation..... 16

Switch 22


Ignition Switch..... 24

Start the engine 25

Shift 26


Refueling 27

Parts Location Diagram




- 1.Instrument Assembly 2.Left handlebar switch 3.Fuel tank cover 4.Clutch handle 5.Chain 6.Flat fork 7.Left front footrest 8.Shift pedal
9.Side bracket 10.Side bracket flameout switch

Parts Location Diagram



- 1.Rearview mirror 2.Right handle switch 3.Brake handle 4.Fuel tank 5.Cushion 6.Engine 7.Rear brake pedal 8.Right front footrest 9.Muffler
10.Front brake fluid reservoir

Instrumentation



Light-sensitive hole

Display Check

When the ignition switch is turned to "ⓘ" (on), the instrument is energized to play the power-on animation, followed by a self-test, and all function modules and symbols are displayed; if the display is missing during the self-test, please refer to the Kove repair shop for repair.

Instrumentation interface



No.	Name	Remark
1	Steering light	The left indicator flashes when the left turn signal comes on
		The right indicator flashes when the right turn signal comes on
2	Message	①Location message (与手机蓝牙连接后)
		②Fault message(when a fault occurs)
		③APP message feed (need to be set in the mobile app)
		④Caller ID display (after connecting with Bluetooth of cell phone)
3	Tachometer	Engine rpm
4	Neutral indicator	The light comes on when in neutral
5	Speedometer	Display the current speed
6	ABS fault indicator	①The light comes on when there is a fault
		②After the whole motorcycle is powered on, this light flashes(0.5s on, 0.5s off) as a normal phenomenon, when the speed exceeds 5km/h, ABS self-test will go off.
7	Gear indication	Show the current gear
8	ABS status	Front and rear wheels show white outline: ABS on front and rear wheels.
		Rear wheel shows yellow fill: rear wheel ABS off
		Front and rear wheel shows yellow fill: ABS off for front and rear wheels.
9	Low voltage indicator	The light comes on when the battery voltage is too low
10	Automatic headlights	The light comes on when the automatic headlight function is on
11	Bluetooth and network	Light up after connecting with Bluetooth or WiFi of cell phone(gray symbol when not connected)

Instrument Interface



No.	Name	Remark
12	Maintenance indicator	This light comes on when the motorcycle reaches the maintenance setting condition
13	Water temperature	① When the water temperature is lower than 0°C, the 1st frame flashes, then you need to confirm whether the coolant is iced or not, and you can start it after confirming that it is normal.
		② When the water temperature indicator block shows red and lights up the "Water Temperature Alarm Light", it means the water temperature is too high, make sure it is safe to stop the car and check it, and then continue driving after the water temperature drops.
		③ When the water temperature data is abnormal, all water temperature color blocks and icons will flash together. (Flashing is normal when the ignition switch is turned off)
14	Gasoline level	Show the gasoline capacity
		① When the fuel level is lower than 1 (after continuing to use for a period of time, the red fuel level will flash with the fuel level symbol), please replenish the fuel as soon as possible. ② If the fuel symbol and all the fuel level color blocks are flashing at the same time, it means that the fuel level signal is abnormal, please go to the special maintenance kove repair shop as soon as possible for maintenance.
15	Temperature	Displayed after connecting to the Bluetooth of the cell phone
16	Weather	Displayed after connecting to the Bluetooth of the cell phone
17	Time	Displayed the time
18	Date/ Easy navigation	Displayed the bike's data (when not navigating) Simple navigation display (need to connect to the Bluetooth of cell phone and set up the navigation in the special APP on the cell phone)
19	Water temperature warning indicator	This light comes on when the water temperature is too high
20	EFI Fault indicator	This light comes on when there is a malfunction in the EFI system (this light comes on when the engine is powered up. It is normal for this fault light to go out after normal startup.)
21	High beam indicator	This light comes on when the high beam is turned on
22	Location indicator	This light comes on when the position light is on

Instrument Full-Screen Navigation Interface



No.	Name	Remark
1	Message tip	Fault message tips, APP push message tips, calling tips
2	Navigation interface	Display full-screen navigation screen
3	Gear indication	Display the current gear
4	ABS status display	Front and rear wheels show white outline: Front and rear wheels ABS on, rear wheels show yellow fill: Rear wheel ABS off Front and rear wheels show yellow fill: Front and rear wheel ABS off
5	Gasoline level	Display the amount of the fuel remaining

Menu description

Primary menu	Secondary menu	Description
Headlights (on/off/auto)	/	The display status here changes according to the headlight mode setting.
ABS setting	All on	Set the ABS working status, and the current ABS working status is displayed through the instrument icon.
	Rear off	
	All off	
Riding data	Trip	Set the vehicle data display items on the main interface, and the selected items are displayed on the first page first (after the number exceeds the number of displayed columns, they are automatically rowed back), and the unselected items are arranged on the next page. Weather conditions can be set to show on or off. Note: 1. The average speed = 0, the average speed shows "---"; 2. The average fuel consumption is affected by many factors such as vehicle working conditions and riding habits, and the display data is for reference only; 3. Long press the BACK button to pop up the subtotal mileage clearance menu, and follow the prompts.
	Speed	
	Consu.	
	Riding time	
	Voltage	
	...	
Setting	Connection	Set up Bluetooth/WIFI connection with mobile phone (in order to ensure normal connection, the mobile phone dedicated APP needs to open relevant permissions according to the prompts; When WIFI is connected, you cannot choose to use the meter WIFI to surf the Internet, otherwise it will affect the mobile phone Internet function).
	Screen	Display mode: Users can modify the instrument display interface according to their preferences.
		Display brightness: Users can modify the display brightness of the meter according to their preferences.
	Headlight mode	When "Automatic Headlights" is selected in the "Headlight Mode" menu, the headlight switch is automatically controlled according to the ambient brightness after the engine is started.
		When selecting "Manual Headlights" in the "Headlight Mode" menu, return to the main interface, and in the first level menu, you can switch the headlight switch.
	Time/date	The instrument's time/date can be set manually by the user. If you select Automatic, when connected with the phone's Bluetooth, it will automatically synchronize with the phone's time.
	Language	Chinese and English menu switching.
	Maintenance	Maintenance mileage or time setting and clearing: the first 2000km, every 500km or 3 months reminder, this default parameter cannot be modified. After that, the user can set the maintenance reminder period according to the actual situation (the default value is every 2000km or 6 months). Maintenance prompt removal method: Press and hold the SET key under the maintenance service interface to pop up the clearing dialog box, and follow the prompt content.
	Unit	Display unit switching

The instrument functions are operated as follows:

Motorcycle data viewing:

Under the main interface of the instrument, you can turn the page by pressing the up and down keys to view vehicle-related data.

Message viewing:

1. When the main interface appears with an information prompt (for example: fault message), you can press SET to view the details, and press the BACK button to clear.
2. When connected with the Bluetooth connection of the mobile phone, the message display section will reflect the mobile phone information push, short press the SET key to view details, short press the BACK button to clear.

Instrument navigation operation:

When normally connected with mobile phone Bluetooth/WIFI, and after setting navigation on the dedicated APP on the mobile phone, press and hold the up button to enter the instrument full-screen navigation, long press the key to enter the instrument simple navigation, and short press the BACK key to exit the instrument navigation interface.

Feature settings:

Press the SET key briefly to enter the gauge menu. ABS mode, instrument brightness, riding data, automatic headlights (on or off), time, language and other parameters can be set according to the man-machine dialogue menu.

Instrument and mobile phone interconnection:


1. The positioning function, navigation function, information push function, weather function, automatic time function, altitude display and other functions in the TFT instrument need to be connected with the mobile phone with the relevant APP installed.
2. Mobile APP installation steps: (1) Enter the instrument setting menu; (2) Select Connection Settings; (3) Select Bluetooth connection, use the Internet-connected mobile phone to scan the QR code in the interface, and download and install the APP according to the prompts. (In order to get a better experience, when using the mobile app, please pay attention to the APP related usage.
3. When the meter needs to be disconnected from the connected mobile phone, enter the reset connection menu and select disconnect Bluetooth or disconnect WIFI.

Note

You need to modify the ABS mode, which must be done while it is parked.

Switch

Left handlebar switch



Instrument combination button:

This combination button is used to set the functions of the meter

▲ ▼ The function selection toggles up and down

BACK Back button

SET Set the instrument function button

Light switch:

☰☐ Turn on the overtaking light (the overtaking light switch is located on the back of the handlebar switch)

☰☐ Turn on high beam

☰☐ Turn on low beam

Danger warning light switch

⚠ use in an emergency, press and switch on the left-hand turn signal or right-hand turn signal at the same time.


Turn signal switch:

➡ Turn on the left-hand turn signal: toggle the switch to the left and return the turn signal switch to its original position after operation.

⬅ Turn on the right-hand turn signal: toggle the switch to the right and return the turn signal switch to its original position after operation.

OFF Turn signal off: When the turn signal switch is in the middle position, press this button to turn off the turn signal.

Right handlebar switch



Emergency flame-out switch:

The engine can only be started when the switch is in the "C" (running) position;

When the switch is in the "⊗" (stop) position, the engine does not start.

► In an emergency, switch to the "⊗" (stop) position to extinguish the engine.

Start button:

When the emergency kill switch is set to the "C" position:

- ① The engine is in neutral, press this button to start the engine.
- ② If the engine is not in neutral, you need to retract the side bracket and pinch the clutch handle, and press this button to start the engine.

Note

- In order to prolong the service life of the switch, it is recommended that you blow out any water that has accumulated inside the switch after washing your car or after a shower such as a rainstorm.

Ignition switch

When the key is in the "❌" position, turn the direction handle to the far left, press the key inward, rotate counterclockwise to "🔒" and pull out the key; To unlock the lock, simply turn the key clockwise.



Position	Function	Remark
❌	Use when parking (motorcycle power off)	The key can be removed
🔒	Use when starting or driving	The key can't be removed



WARNING

- When parking (including long stops), the ignition switch must be placed in the "❌" or "PUSH" position to ensure vehicle safety and prevent battery "battery loss".
- Do not push the motorcycle with the steering mechanism locked, otherwise it will lose its balance.

Start the engine

Whether the engine is hot or cold, follow the instructions below to start the engine.



1. Rotate the ignition to the “○”(on) position.
2. Switch gear to neutral (N neutral indicator lights up).
3. Pull the button down and hold it until the engine starts.

If the engine does not start:


If the engine does not start within 3 seconds, wait 10 seconds before repeating step 3.

Note

- Prolonged high-speed idling and idling can damage the engine and exhaust system.
- Jerking the throttle or idling at high speed for more than 5 minutes may cause discoloration of the exhaust pipe.
- If the throttle is fully open, the engine will not start.

Shift gears

Your motorcycle has 6 forward gears with a shift mode on 1 under 5.



Way to change gears:

Warm up the engine to keep it running normally.

1. When the engine is idling, disengage the clutch and press the gear shift pedal down so that the transmission enters the low gear (first gear) position.

2. Gradually increase the engine speed, slowly release the clutch handle, these two actions coordinate and cooperate to ensure a natural start.


3. When the motorcycle reaches a balanced driving state, reduce the engine speed and then disengage the clutch, hook the gear pedal upwards into the second gear, and so on, and the rest of the gear changes can be carried out in the same way.

Things you should pay attention to while driving:

1. Avoid unnecessary engine idling, and do not allow the engine to idle at high speed, otherwise it will seriously damage the parts.
2. The clutch is driven in a semi-disengaged state, which will make the clutch plate wear out quickly.
3. If you feel that the engine horsepower is insufficient when climbing, you should switch to low gear in time.
4. In driving, especially downhill and high-speed driving, it is not allowed to use the front brake alone or neutral coasting, and it is not allowed to drive without the handle.
5. When parking, retract a small throttle while cutting off the clutch and then braking.

Refueling

Your motorcycle is equipped with 2 fuel tanks located on the left and right sides of the motorcycle body, the two tanks have a total capacity of 14L and need to be filled with fuel separately. It is recommended to use 92# or above unleaded gasoline.



Open fuel tank cap: rotate counterclockwise.

Close fuel tank cap: turn and tighten the tank cap clockwise, so that the snorkel cannot be twisted during the tightening process.

When filling fuel:

After stopping using the side bracket, open the fuel tank cap for filling, and after injecting fuel, close the fuel cap.

Avoid overfilling the fuel, pay attention to the change of oil level during the addition process, and it is recommended that the addition amount should not exceed 90% of the total capacity of the tank (to avoid the expansion of fuel due to heating).



WARNING

- When refueling, please do it outdoors, be sure to turn off the engine, keep away from heat, sparks or open flames, and wipe clean immediately if splashed.

Maintenance

Please read the "Maintenance" and "Maintenance Specifications" carefully before preparing for maintenance. For maintenance data, please refer to "Technical Parameters".

Maintenance	29
Maintenance cycle table	30
Maintenance specifications	31
Replace parts	32
Disassembly and installation of body components	40
Engine oil and oil concentrate filters	42
Oil and gas separator	44
Coolant	45
Brake	46
Side brackets	48
Drive chain	49
Clutch	51
Throttle	52
Front shock absorber adjustment	53
Rear shock absorber adjustment	57
Headlight	62

Maintenance

The importance of maintenance

It's important to keep your motorcycle in good service condition, which is essential for your safety, as well as protecting your property, getting the best performance, preventing breakdowns and mitigating air pollution.

Maintenance is an important responsibility of motorcycle owners, ensuring that inspections are carried out before each ride and that regular inspections are carried out as described in the maintenance cycle table.

Follow these guidelines for maintenance:

- Turn off the engine and remove the key.
- Park the motorcycle on a firm and flat ground with a side bracket or support it with a maintenance bracket.
- Please wait for the engine, muffler, brake, and other hot parts to cool down before starting operation, otherwise it may cause burns.
- Please start the engine under specified circumstances and in a well-ventilated environment.


WARNING

- Failure to perform proper maintenance prior to riding or to properly remove malfunctions may result in serious injury or fatal accidents.
- Follow the inspection, maintenance recommendations and maintenance cycle table provided in the instruction manual.

Maintenance cycle table

The motorcycle should be maintained within the specified time, and for safety, it should only be serviced by the Kove repair shop.

The symbols in the table have the following meanings:

I: Inspection, cleaning, adjustment R: replacement A: adjustment L: lubrication

Items	Times	Project Period	MILEAGE TABLE km(Remark2)									
			1000km/m/3M	3000km/6M	6000km/6M	7000km/6M	9000km/6M	11000km/6M	16000km/6M	21000km/6M	26000km/6M	30000km/6M
*	Fuel system oil circuit		I		I		I		I	I	I	I
*	Fuel Filter		R 10000km/1year									
*	Throttle Operation System		I	I	I	I	I	I	I	I	I	I
*	Air filter element	Remark 1	1000km or 1 month for replacement, daily for venue or desert rides									
*	Spark plug				I			R		R		R
**	Exhaust valve clearance		I 2000km/30 hours									
**	Intake valve clearance		I 2000km/30 hours									
*	Engine oil		For the first 2000km, replace every 500km, after 2000km, replace every 1000km									
*	Oil Filter		Change it together with the oil change									
*	Timing Chain Tension		A	A	A	A	A	A	A	A	A	A
**	EFI system		I		I		I		I	I	I	I
*	Drive Chain		I、L	I、L	I、L	I、L	I、L	I、L	I、L	I、L	I、L	I、L
*	Battery	Every month	I		I		I	I	I	I	I	I
*	Brake shoes wear		I	I	I	I	I	I	I	I	I	I
**	Brake System		I	I	I	I	I	I	I	I	I	I
*	Headlight dimming		I		I		I	I	I	I	I	I
*	Clutch		I Pavement 5000km/non-pavement 20 hours									
**	Fastener		I	I	I	I	I	I	I	I	I	I
**	Directional bearing		I	I	I	I	I	I	I	I	I	I
**	Coolant		R 30000km/2years									
**	Shock absorber oil		R 5000km/100 hours									

*: The item is repaired by the personnel of the special repair store of Kove repair shop. If the user has special tools, repair parts and repair ability, he can also repair by himself, and the repair knowledge can refer to this instruction manual.

** : To ensure safety, this project can only be repaired by the personnel of the special repair store of Kove.

Remark:

1.When driving in dusty areas, such as deserts or grounds, the air filter element needs to be changed or cleaned daily

2.When the odometer reading exceeds the highest number given, its maintenance interval is still repeated at the mileage interval specified in the table.

3.The motorcycle maintenance interval should be reduced by 50% when the motorcycle is frequently used in harsh conditions.

Service outlets: _____
 (official seal of the unit)

Service Personnel: _____
 User Signature: _____
 Date: _____

Maintenance specifications

To ensure safety, it is your responsibility to conduct a pre-ride inspection and ensure that any problems you find have been corrected. A pre-ride check is required.

Items	Content
Handlebar	Flexible rotation, no clearance and loosening
Brake system	Check its health, check the front and rear brake fluid levels and the amount of brake pad wear
Fuel level	Sufficient fuel storage for the planned distance (refueling if necessary)
Throttle	Check that it opens smoothly and closes completely in each steering position
Clutch	Check its health and, if necessary, adjust the free stroke
Wheels and tires	Check its condition of use and tire pressure, and replenish air pressure if necessary
Drive chain	Check its condition and sag status, adjust and lubricate if necessary
Lighting, horns	Check whether the lighting system and horn performance is good
Oil level	If necessary, add engine oil and check for leaks
Instrument indication	Check whether the indicators on the meter are displayed normally

Replace parts

Battery

Check and replace the battery

1. Before battery installation, if the electrode is found to be dirty, please wipe it clean before installing, otherwise it may cause functional failure due to poor contact.
2. If the battery is deformed, abnormally heated, smoked and other abnormal phenomena during use, please stop using it immediately and go to the Kove repair shop in time for investigation.
3. If the battery is placed in a high temperature and humid environment for a long time, there may be a functional failure, life-shortening, etc., before using it again, please ensure that the appearance and function of the battery are normal before installation and use.
4. If the whole motorcycle cannot be started, please check whether the battery is normal, if the battery is damaged, please replace it in time.
5. When installing the battery, be sure to lock the battery pole bolts.

If the battery has not been used for a long time, please pay attention to the following situations:

- In order to prevent the occurrence of over-discharge, the battery should be charged once every 2 months.
- When the battery is not in use, it should be placed in a cool and dry environment and prevent short circuit of the positive and negative poles of the battery.

Note

- Improper disposal of batteries may cause harm to the environment and human health, please dispose of disposed of batteries in accordance with local environmental protection regulations.
- Adding motorcycle electrical appliances may cause battery loss and even cause electrical system failure.


Fuse

Fuses protect your motorcycle's circuitry, if some electrical parts on your motorcycle stop running, check and replace the blown fuse.

Check and replace the fuse

Turn the ignition to the "  " (off) position, remove and check the fuse. If the fuse blows, replace it with a fuse of the same size. For fuse specifications, please refer to "Technical Specs".

If the fuse is often blown out, there may be hidden problems in the electrical appliance, please leave it to Kove Repair Shop for repair.



Note

- Fuses need to be replaced in equal amounts, if you replace a higher rated fuse will increase the chance of damaging the electrical system and risk burning the bike.
- Installing non-Kove electrical fittings can overload the electrical system, cause the battery to discharge, and even damage the system.

Engine oil

The consumption of engine oil and the drop in oil quality will vary depending on the riding conditions and use time, the higher the operating speed, the faster the oil consumption rate, long-term high-speed or high-speed operation, should shorten the oil change interval, check the engine oil level frequently, if necessary, add the recommended engine oil.

When used in extreme temperatures, the oil quality drops faster, and the oil that has become dirty or has been used for a long time should be replaced as soon as possible.

Select engine oil

The oil should be SN grade of API classification, and its grade is SN10W-40.

Brake fluid

Do not add or replace brake fluid except in an emergency.

Use only brake fluid freshly removed from the sealed container, and if you add brake fluid, have the brake system checked by a Kove repair shop as soon as possible.

Coolant

Only the original undiluted Kove pre-mixed coolant can be used, the original Kove pre-mixed coolant can be excellent in preventing corrosion and overheating, please pay attention to the coolant capacity, if the liquid level is lower than the lower limit, please add it in time. Coolant freezing point -40°C , boiling point 110°C .

Note


- Brake fluid can damage plastic and paint surfaces, so wipe it off immediately and wash it thoroughly.
- Recommended brake fluid: DOT4 brake fluid or equivalent.
- The use of coolant dedicated to non-aluminum engines, ordinary tap water or mineral water can cause corrosion.

Drive chain

The drive chain must be checked and lubricated regularly. If you are constantly driving in poor road conditions, driving at high speeds, or repeatedly increasing the speed, you need to check the chain more often.

If the drive chain does not run smoothly, makes abnormal noises, has damaged rollers or loose latches, or the oil seal is missing or bent, please refer the chain to Kove Repair Shop for inspection.

Also check the active sprocket and driven sprocket, if any of them have worn or damaged teeth, please take it to the Kove repair shop for replacement.



Note


- Using a new drive chain on a worn sprocket will accelerate chain wear, and both the drive chain and sprocket should be replaced at the same time.
- Recommended lubricant: chain oil seal special lubricant SAE80 or 90 gear oil.

Clean and lubricate

After checking the sagging, turn the rear wheel while cleaning the chain and sprocket, you can use a dry cloth, special cleaner for the oil seal chain or neutral detergent, if the chain is dirty, you can use a soft brush; After cleaning, wipe dry and lubricate with the recommended oil.

Do not use steam cleaners, high-pressure cleaners, wire brushes, volatile solvents such as gasoline and benzene, scrubs, chain cleaners and lubricating oils that are not dedicated to oil seal chains, otherwise the chain oil seal may be damaged.

Avoid getting oil on the brakes or tires, and avoid using excessive amounts of oil to avoid splashing on clothes or motorcycles.



Tires (inspection/replacement)—tube

Check the specifications

Front wheel: External tire: 90/90-21 M/C 54R Inner tube: 2.75/3.00-21 Belt: Liner 21×30mm

Rear wheel: External tire: 140/80-18 M/C 70R Inner tube: 4.50/4.75/5.10-18 Belt: Liner 18×30mm

Abnormal wear check

Check the contact surfaces of the tires for signs of abnormal wear.

Check the depth of the tread

Check the contact surfaces of the tires for signs of abnormal wear.


Check your tire pressure

When you feel that the tire pressure is low, visually inspect the tire and measure it with a barometer, check the tire pressure while the tire is cool, and check the tire pressure at least once a month. Make sure the valve core cap is fastened and, if necessary, replace it with a new one.

TP standard value: Front tire: 230KPa; Rear tire: 250KPa.

Injury examination

Check the tires for cuts, cracks, exposed fabric, tire cords, nails or other foreign objects embedded in the tire's sidewall tread, as well as any unusual bulges or swellings in the tire's sidewalls.



Whenever you change your tires, follow these guidelines:


- Use recommended tires or equivalent products with the same size, construction, speed class and load capacity.
- After the tires are installed, use the original balance positioner or equivalent equipment of Kove to balance and position the wheels.
- When changing tires, be sure to replace the inner tube, the old inner tube may have been deformed and if it is installed on a new tire, it will also cause cracking.



WARNING

- Using over-worn or improperly inflated tires can lead to accidents and serious injuries, please follow the relevant tire maintenance guidelines in the instruction manual.
- Installing unsuitable tires can affect handling and stability and lead to accidents that can seriously injure you or even endanger your life.
- Always use the size and type of tires recommended in this instruction manual.

Air filter



The air filter drain is located at the lower end of the air filter, every 3 months you need to check whether there is water or oil in the drain, if you clean the motorcycle or after heavy rain should be checked in a timely manner, if there is, remove the plug under the air filter drain for discharge, discharge clean and then install the plug.

This motorcycle is equipped with an air filter element made of paper, please do not maintain it yourself, it should be cleaned or replaced by Kove repair shop.

If you ride on dusty roads, the air filter element should be cleaned or replaced every 3 days depending on the conditions, and daily in desert conditions.

Note

- The air filter needs to be checked for any looseness in the 4 nuts inside after removal and the bolts and nuts must be tightened.


Tools

You can use the on-board tool for simple repairs, minor adjustments, and parts replacement.

- Double-ended screwdriver
- Double head wrench 8×10
- Double head wrench 12×14
- Allen Key 6
- Double-ended internal wrench $T25 \times T30$
- Fishtail pliers

Disassembly and installation of body components

Battery



Disassembly


Confirm that the ignition is turned to the "⊗" (off) position.

- 1.Remove the seat cushion.
- 2.Loosen the rubber band from the rear side.
- 3.Disconnect the negative (-) terminal of the battery.
- 4.Disconnect the positive (+) terminal of the battery.
- 5.Remove the battery and be careful not to leave bolts and nuts behind.

Installation

Install the parts in the reverse order of removal, always connecting the positive terminal first (+) terminal, and finally the negative (-) terminal, make sure that the bolts and nuts are tightened.

Seat



Disassembly

Pull the seat lock cable down while pulling the rear end of the seat up to disengage from the lock, then remove the seat diagonally backwards.

Installation


1. Snap the front and rear latches of the seat assembly into the frame card slots.
2. Align the seat lock pin and lock hole, press down the back of the seat, the lock pin is inserted into the seat lock hole, and is automatically locked by the lock tongue. Gently pull up to ensure the seat cushion is securely locked in place.
3. When the seat is closed, the seat lock will lock automatically.

Note

- Please ensure that the seat latch is inserted accurately into the frame card slot, otherwise the seat product will not be able to support your weight and the seat product may be crushed.

Engine oil and oil concentrate filters

Replace the engine oil and oil concentrate filter



Changing engine oil and oil concentrate filters requires special tools, which we recommend being done by Kove Repair Shop. Please refer to the "Maintenance Cycle Table" for engine oil and oil concentrate filter maintenance intervals.

Use the original engine oil and oil concentrate filter of Kove for your model.

1. If the engine is cold, please idle for 3-5 minutes; Rotate the ignition to the "❌" (off) position and wait another 2-3 minutes;

2. Park the motorcycle on a stable horizontal surface and place an oil drain tray under the oil drain bolt;

3. Remove the oil filter cover of the left and right boxes and take out the oil filter;

4. Remove the oil fine filter cover and spring, and take out the oil fine filter;

5. Remove the engine oil injection cap, oil drain bolt and sealing gasket, and remove the oil until the oil is droplet;

6. Replace a new oil fine filter, and then install the spring and oil fine filter cover in turn; (Torque: 11~13N·m).

7. Reinstall the cleaned oil filter into the left and right boxes and tighten the oil filter cover; (Torque: 11~13N·m).

8. Install a new sealing gasket on the oil drain bolt and tighten the oil drain bolt; (Torque: 24~27 N·m).

9. Add the recommended original engine oil to the crankcase. After filling, tighten the oil injection port cap; (Torque: 4~6N·m).

When replacing the oil fine filter, the amount of oil required: 1.6L

When disassembling the engine and reassembling it, the amount of oil required: 1.8L

10. Check whether the oil is leaking.

Precautions for replacing engine oil and oil

concentrate filter:


1. Using the wrong engine oil and oil concentrate filter can seriously damage the engine.
2. Excessive refueling or insufficient oil will damage the engine, do not mix different brands and grades of oil, which will affect lubrication and clutch operation.
3. When changing the oil, it is necessary to replace the new oil fine filter and clean the left and right oil filter.
4. When installing the oil fine filter, it should be noted that the opening end of the oil fine filter should face the left body.
5. Long-term contact with engine oil should be avoided, and it should be thoroughly washed after contact with engine oil.
6. Used oil, oil concentrate filter and container are harmful to health and the environment, can not be treated as daily garbage, treatment methods should be in line with local environmental protection regulations.

Oil strainer inspection and cleaning

The oil filter should be inspected and cleaned every time the oil is changed, and should be replaced in time if any damage is found.

1. Remove the oil filter cover from the left and right cases;
2. Remove the oil filter with sharp-nosed pliers;
3. Flush it with clean gasoline until the oil filter is flushed clean;
4. Reinstall the clean oil filter into the case;
5. Install the oil filter cover. (Torque: 11~13N·m)


Oil and gas separator



During daily maintenance, check the liquid collection tube, if there is fluid accumulation in the collection tube, it needs to be discharged in time.

Remove the plug under the collection tube, let it sit for a while, drain the oil or water, and then install the plug.

Coolant



WARNING

- Do not remove the radiator cap when the engine is not cooled down, as this will cause coolant to spray out and may cause you burns.

Check the coolant

While the engine is cooling, check the coolant level in the jug.

1. Park the motorcycle on a stable level and keep the motorcycle upright.
2. Check that the coolant level is between the upper and lower limit level marks.
3. If the liquid level drops significantly or the storage tank is empty, serious leakage may occur, please hand over to Kove Repair Shop to overhaul the motorcycle.

Add coolant

If the coolant level falls below the lower limit mark, add the recommended coolant until the level reaches the upper limit mark. When adding coolant, only from the lid of the water storage jug.

1. Remove the storage jug cover, add coolant, and pay attention to the coolant

- Do not exceed the upper limit.
- Make sure no foreign objects enter.


2. Reinstall the cover.

Change the coolant

Unless you have the right tools and qualified mechanical skills, have the coolant changed by an authorized Kove Repair Shop.

Brake

Check the brake fluid



1. Place the motorcycle vertically upwards on stable flat ground.

2. Check that the brake fluid reservoir is level.

3. Check whether the brake fluid can be seen in the oil window, if the brake fluid is lower than the lower limit of the oil window, please add it immediately.

If the brake fluid level in the reservoir is below the lower level mark (LWR), or if the free stroke of the brake lever and pedal exceeds the mark, the brake pads must be checked for wear, if they are not worn, there may be a leak, please have them serviced by an authorized Kove repair shop.

Check the brake pads

Check the condition of the brake pad wear indicator mark, if the brake pad is worn to the indicator mark, it needs to be replaced.


F

- Check the brake pads from under the calipers
- Brake pad lining thickness: 3mm (indicated as wear limit)

R


- Check the brake pads from the right rear of the caliper
- Brake pad lining thickness: 5.4mm (indicated as wear limit)

If necessary, please take the brake pads to the Kove Repair Shop to replace the brake pads, when the wear limit is reached, the left and right brake pads must be replaced at the same time.



Side bracket

Check the side bracket



1. Check whether the side bracket operates freely, if the side bracket operation is stuck or makes a “squeaking” sound, clean the pivot area and lubricate the pivot bolt with clean grease.

2. Check whether the spring is damaged or loses its elasticity

Drive chain


Check the sag of the drive chain

Check the sag of different points along the chain, if not all points have the same sagging, some links may have been bent and kinked, please leave the chain to the Kove repair shop.

1. Hook the transmission into neutral and turn off the engine.
2. Place the motorcycle vertically on a stable and flat ground.
3. In the area behind the chain guard, push the chain in the direction close to the flat fork to determine the sag of the chain.
4. Turn the rear wheel forward to check whether the chain runs smoothly.
5. Check the sprocket.
6. Clean and lubricate the drive chain.

Drive chain sagging: 35-45mm

If the sag exceeds 55mm, you can't continue to ride the motorcycle.




Sag schematic

Note

- When checking the drape of the drive chain, make sure that the upper part of the chain must be tensioned.

Adjust the sag of the drive chain




Chain tightness: 35-45mm

Note

- When adjusting the drive chain sag, make sure that the upper part of the chain must be tensioned.


When adjusting the drive chain sag:

1. Hook the transmission into neutral and turn off the engine.
2. Place the motorcycle vertically on a stable and flat ground.
3. Loosen the rear axle nut.
4. Use an open wrench to loosen the lock nut and chain tightening adjustment nut.
5. Rotate the chain tightness adjustment nut to adjust the tightness of the chain, the chain tightness adjustment range is: 30-55mm.
6. In the middle position of the upper part of the rear flat fork, push the chain in the direction of the flat fork to determine the reasonable sag of the chain.
7. The left and right sides of the sag are adjusted on the same tick line.



Clutch

Free stroke of clutch lever: 10–15mm



Check whether the clutch cable is bent or broken. If necessary, please leave it to Kove repair shop for replacement.

Please lubricate the clutch cable with a special cable oil to prevent premature wear and corrosion.

Note

- Incorrect adjustment of free travel can cause premature clutch wear.


Throttle

Check the throttle


When the engine is off, check that the throttle smoothly shifts from full off to full open in all directions and that the free stroke is correct.

If the throttle operation is not smooth, the automatic closing or the cable is broken, please refer it to the Kove repair shop for maintenance.

Free stroke of throttle handle flange: 2-6mm



Adjust the brake lever



You can adjust the distance from the top of the brake lever to the handlebars.

Methods of adjustment


Rotate the adjusting bolt in a counterclockwise direction, and the brake handle is close to the handlebar; Rotate the adjusting bolt clockwise and keep the brake handle away from the handlebar.

The adjustment range is limited, do not screw the adjustment bolt beyond its natural limit.

Adjustments are not allowed while driving.

Front shock absorber adjustment

Air pressure adjustment



The shock absorber generates air pressure internally when it is worked, and the air pressure is like a progressive spring that affects the entire stroke of the motorcycle. On long rides, the front shock gets stiffer. Therefore, it is necessary to release the air pressure inside the front shock absorber in time.

You can use pressure exhaust bolts to release the air pressure that has built up inside the front shock absorber. Before releasing pressure, be sure to make sure that the front tires are off the ground, at which point the front shock absorbers are fully extended.


Methods of adjustment:

1. Place an optional table under the engine to lift the front wheels off the ground.
2. Remove the pressure exhaust bolt.
3. Coat the O-ring with No. 2 lithium grease and install it.
4. Tighten the pressure exhaust bolt. (Torque: $1.3\text{N}\cdot\text{m}$)

Note

- When discharging the air pressure of the shock absorber before discharging, if the O-ring is broken, it should be replaced in time.
- The front wheel adjusts the air pressure on the ground, which gives the wrong degree of pressure.


Front shock absorber inspection



Regularly inspect and clean all components of the front shock absorber to ensure the best performance of the front shock absorber:

1. Check that the front shock absorber decoration and dust seal are clean and not stuffed with mud and dirt.
2. Check for oil stains under the shock absorber dust seal, if there are signs of oil leakage, replace the damaged dust seal and oil seal.
3. Check the wear ring for wear or damage. If the wear ring is less than 1.7mm in diameter or flush with the outer barrel, the wear ring needs to be replaced. When replacing the wear ring, remove the bottom barrel and install the wear ring so that the end gap position is towards the rear of the motorcycle.
4. Squeeze the brake handle and press down on the handlebars a few times to check that the front shock absorber rebounds smoothly.

Compression damping adjustment



The compression damping adjustment affects the rate of front shock absorber compression. Front shock absorber compression damping is adjustable in multiple stages. Each segment is 1/4 turn. Turning the compression damping adjustment bolt one full turn turns the adjuster 4 segments.

Turning the adjusting bolt clockwise (H) stiffens the compression damping, and turning the adjusting bolt counterclockwise (S) softens the compression damping.

Note


- Do not rotate the adjusting bolt beyond the given position, otherwise you may damage the adjusting mechanism. The adjustment torque does not exceed $0.5\text{N}\cdot\text{m}$.

Set standard compression damping:

1. Turn the compression damping adjustment bolt clockwise until it no longer rotates;
2. Then turn the adjusting bolt counterclockwise, the standard compression damping is from the hardest position counterclockwise turn 10 sections, hear the click position.

You can adjust it according to your weight and riding conditions, making sure that the adjustment bolts stop in the clicking position and the left and right ends are adjusted to the same position with each adjustment.

Rebound damping adjustment



Rebound damping
adjustment bolt

The rebound damping adjustment affects how fast the front shock absorber rebounds. Front shock absorber rebound damping is adjustable in multiple stages. Each segment is 1/4 turn. Turning the rebound damping adjustment bolt one full turn turns the adjuster 4 segments.

Setting the standard rebound damping:

1. Turn the rebound damping adjustment bolt clockwise until it no longer rotates;
2. Turn the adjusting bolt counterclockwise (lighter), the standard rebound damping is 10 segments from the hardest position, and a click is heard.


You can adjust it according to your weight and riding conditions, making sure that the adjustment bolts stop in the clicking position and the left and right ends are adjusted to the same position with each adjustment.

Note

- Do not rotate the adjusting bolt beyond the given position, otherwise you may damage the adjusting mechanism. The adjustment torque does not exceed 0.5 N·m.
- Both compression damping and rebound damping can be increased by rotating the adjustment bolt clockwise.

Rear shock absorber adjustment

Airbag



The rear damping assembly consists of a damping airbag containing high-pressure nitrogen. Do not attempt to disassemble, repair or dispose of the device, piercing or exposure to flames may also result in an explosion causing serious injury. Repair or disposal should be done by Kove repair shop.

Spring preload adjustment

Spring preload should be adjusted while the engine is cool by turning the shock spring lock nut and adjusting nut to adjust the spring preload.

Adjustment method:

1. Firmly support your motorcycle with a maintenance bracket or crane and lift the rear wheels off the ground.
2. Check whether the spring preload is at the standard length.
3. Loosen the shock absorber spring lock nut, rotate the adjustment nut, and the spring length will change by 1.5mm for each turn of the adjustment nut.
4. Adjust accordingly to the needs.
5. After the adjustment is completed, hold the adjustment nut and tighten the damping spring lock nut (Torque: 44N·m)

High Seat Version:

Increase spring preload:

Loosen the shock absorber spring lock nut with a special tool, turn the adjusting nut, shorten the spring length, the shortest must not be less than: 215mm.

Reduce spring preload:

Loosen the locking nut of the damping spring with a special tool, turn the adjusting nut and increase the length of the spring up to a maximum of: 230 mm.

Each turn of the adjustment nut will change the spring length and spring preload.

Low Seat Version:

Increase spring preload:


Use a special tool to loosen the damping spring lock nut, turn the adjustment nut, shorten the spring length the shortest must not be less than: 200mm.

Reduce the spring preload:

Use a special tool to loosen the damping spring lock nut, turn the adjustment nut, increase the spring length, the maximum is not higher than: 225mm.

Each turn of adjustment nut will change the spring length and spring preload.

Compression damping adjustment



The compression damping can be adjusted in 2 stages by adjusting the bolt separately for high speed compression damping and low speed compression damping, you can adjust accordingly to your weight and riding conditions.

When adjusting the compression damping adjusting bolt, be sure to use the appropriate size tool to avoid damage.


High-speed damping adjustment

When it is necessary to adjust the compression damping for high-speed movement of the shock absorber, adjust the hexagonal portion of the compression damper with approximately 4 turns of adjustment travel. Compression damping increases with clockwise (H) adjustment and decreases with counterclockwise (S) adjustment.

Adjust to the standard position:

1. Turn the adjusting bolt clockwise (H) until it cannot be turned.
2. Turn the adjusting bolt counterclockwise 2 turns from the hardest position.

Compression damping adjustment



Low-speed compression damping adjustment

When it is necessary to adjust the compression damping of the shock absorber for low-speed movement, adjust the center one-bolt portion of the compression damper, which is adjustable in multiple segments, each segment being 1/4 turn. Compression damping increases with clockwise (H) adjustment and decreases with counterclockwise (S) adjustment.


Adjust to standard position:

1. Turn the adjusting bolt clockwise (H) until it cannot be turned.
2. Turn the adjusting bolt counterclockwise by 8 segments from the hardest position to the position where a clicking sound is heard.

Note

- Low-speed compression damping adjustment torque not exceeding 0.5N·m.

Rebound damping adjustment



The rebound damping adjusting bolt is located at the lower left end of the rear shock absorber. Turn the adjusting bolt clockwise to increase rebound damping (hard) and counterclockwise to decrease rebound damping (soft).

Note

- Turn the adjusting bolt gently to prevent damage to the rear shock absorber.
- When adjusting the rebound damping adjusting bolt, be sure to use the proper size tool to avoid damage.
- Make sure the adjusting bolt is firmly located in the fixed position during each adjustment.
- The adjustment torque should not exceed $0.5\text{N}\cdot\text{m}$.


Setting the standard rebound damping:

1. Turn the rebound damping adjusting bolt clockwise (H) until it cannot be turned;
2. Turn the adjusting bolt counterclockwise (S), the standard rebound damping is from the hardest position to turn counterclockwise for 10 segments, hear the clicking sound position.

Headlight

Adjusting the headlight beam

You can adjust the headlight beam angle by turning the adjusting screw, turn clockwise to lower the headlight beam as a whole; turn counterclockwise to raise the headlight beam as a whole, please observe local laws and regulations.



Troubleshooting

Please read "Maintenance" and "Maintenance Specification" carefully before maintenance, please refer to "Technical Specs" for maintenance data.

The engine doesn't start	64
The warning light is on or flashing	65
Puncture the tire	66
Disassemble the tire	67
Electrical failure	71

The engine doesn't start

The starter motor runs, but the engine fails to start

Check the following items:

- Check that the correct engine starting sequence is being used.
- Check the tank for gasoline.
- Check whether the battery voltage is too low.
- Check that the side stand flame out switch and side tilt sensor are working.

The starter motor isn't working

Check the following items:

- Confirm that the engine starting sequence is correct.
- Make sure the engine flameout switch is in the running position.
- Check for low battery voltage, blown fuses and loose battery connections, if the problem persists, have it serviced by an authorized Kove repair shop.

Note

- Continuing to ride while the engine is overheating can seriously damage the engine.
- The engine runs at high speed in neutral gear for a long time, which may cause the water temperature to be too high alarm.

Overheating (water temperature alarm indicator on)

If the engine overheats when the water temperature alarm indicator is on and the speed is slow, please push the motorcycle to a safe side of the road and take the following measures:

1. Turn off the engine with the ignition switch and rotate to the "○" (on) position.

2. Check whether the radiator fan is running normally, and then turn the ignition switch to the "⊗" (off) position.

If the fan isn't running: Do not start the engine and take your motorcycle to a Kove repair shop.

If the fan is running: Leave the ignition in the "⊗" (off) position and wait for the engine to cool.

3. After the engine cools down, check whether the radiator hose is leaking.

If there is a leak: Do not start the engine, transport your motorcycle to the Kove Repair Shop for service.

4. Check the coolant level in the reservoir and add if necessary.

5. If all 1–4 checks are normal, you can continue riding, but keep an eye on the indicators.

The warning light is on or flashing

ABS fault indicator (Anti-lock Braking System)

If any of the following conditions appear in the ABS fault indicator, it means that your ABS is faulty, and the emergency braking will not be able to provide anti-lock braking function, please hand it over to Kove repair shop for maintenance as soon as possible.

- The ABS fault indicator is solid or flashing while riding
- When the ignition switch rotates from “”(off) to “” (on) state, the indicator doesn't light up.
- The speed is higher than 5 km / h, the indicator doesn't go out.

The ABS malfunction indicator may flash or stay on when the following conditions occur:

- Turn the front wheels individually.
- Turn the rear wheels individually.
- The rear wheels slip.
- When riding on special surfaces.

The system can be reset by turning the ignition switch to the “” (off) position and then to the “” (on) position.

EFI fault indicator

If the EFI fault indicator lights up while riding, there may be a serious problem with your EFI system. Please slow down and hand over to the Kove repair shop for maintenance as soon as possible.

Puncture the tire

If a tire is punctured or damaged, replace it, not repair it. Repaired tires, which do not perform as well as new ones, may break while you are riding. Replacing a tire requires special tools and expertise, and we recommend leaving this type of repair to Kove repair shop.




WARNING

- Riding a motorcycle with temporarily repaired tires is dangerous, and if the temporary repair fails, an accident will occur, resulting in serious injury or death.
- If you must ride a motorcycle with temporarily repaired tires, please ride carefully and slowly, not exceeding 50 km/h, until new tires are put on.

Disassemble the tire

Front wheel

If you need to remove the wheel to repair the tire, follow these steps, being careful not to damage the wheel speed sensor and ABS ring gear when you remove and install the wheel.



Disassembly

1. Securely support your motorcycle with a maintenance stand or crane and lift the front wheel off the ground.
2. Loosen the front axle nuts and the left and right axle locking bolts.
3. Pull the front axle out of the hub and remove the front wheel.

Installation


1. Clean the front axle and front shock absorber mount holes and apply grease evenly around the front hub oil seal.
2. Place the front wheel in the middle of the front shock absorber and at the same time snap the brake disc into the brake caliper, taking care not to damage the brake pads.
3. Put the front axle through the front shock absorber and wheel hub from right to left, and tighten the front axle nut and the locking bolts on the left and right sides. (front axle M16, torque: 88N·m; front axle locking bolt M8, torque: 22N·m)
4. Place the front wheel on the ground.
5. Operate the brake handle several times, then shake the fork up and down several times.
6. Raise the front wheels off the ground again and check that the wheels turn smoothly after you release the brake handle.

If a torque wrench is not used during installation, please take it to a special Kove repair shop as soon as possible, improper installation can lead to a decrease in brake performance.

Note

- When installing wheels or calipers into place, to prevent scratching them, please install the discs between the brake pads carefully, a damaged disc will affect the braking effect.
- When installing the front wheel, the front axle must be tightened first, followed by tightening the locking bolts on the left and right sides of the front axle, and the order of the two cannot be switched.

Rear wheel



Disassembly

1. Park the motorcycle on a stable level surface.
2. Securely support your motorcycle with a maintenance stand and raise the rear wheel off the ground.

3. Remove the rear axle nut.
4. Hold the rear wheel and pull out the rear axle.
5. Removing the drive chain from the drive sprocket.
6. Remove the rear wheel.
7. Remove the rear brake caliper assembly from the flat fork slot.
 - Support the brake caliper assembly, do not hang on to the brake hose and do not twist the brake hose.
 - Avoid getting lubricant, oil or dirt on the brake discs or pads.
 - Do not operate the brake pedal when the brake caliper is removed.
 - Be careful to prevent the brake caliper from scratching the wheel during removal.

Installation

1. Check whether the rear wheel bearing is damaged, if the bearing is damaged, the rear wheel bearing needs to be replaced and apply grease evenly in the groove between the main and sub lips of the oil seal and around the circumference.

2. Clean the rear axle and rear flat fork mounting holes.

3. Snap the rear brake caliper assembly into the rear flat fork slot.

4. Push the rear wheel into the rear flat fork, and at the same time snap the brake disc into the brake caliper, taking care not to damage the brake pads.

5. Reinstall the drive chain on the drive sprocket.

6. Insert the rear axle and turn the rear wheel so that the drive chain and the drive sprocket are fully seated.

7. Tighten the rear axle nut, torque: 128N·m


If a torque wrench is not used during installation, please take it to Kove repair shop as soon as possible, improper installation can lead to a decrease in brake performance.

Note

- When installing wheels or calipers in place, install the discs between the brake pads carefully to prevent scratching.

Electrical failure

The fuse is blown



Fuse replacement

1. Remove the seat.
2. Open the fuse box cover, take out the fuse, and check whether the fuse is blown. If it blows, be sure to replace it with a spare fuse of the same specification.
3. Close the fuse box cover and install the seat.

The battery is dead

Please charge the battery with a special charger for motorcycle lithium batteries, and remove the battery from the motorcycle before charging. If the battery still does not recover after charging, please contact the Kove Repair Shop.

Note

- It is forbidden to charge with a car battery charger or motorcycle lead-acid battery charger, which may cause battery damage or even fire.
- Before handling the fuse, refer to "Checking and Replacing the Fuse".

Related information

Key	73
Gauges, controls, and other features	74
Maintenance of motorcycles	75
Storage of motorcycles	78
Transportation of motorcycles	78
You and the environment	79
Frame number, engine number, nameplate	80
Catalytic converters	81

Key

Ignition key



The motorcycle has two ignition keys, which are used to start the engine.

- Do not bend the key or subject it to excessive pressure.
- Avoid prolonged exposure to the sun or high temperatures.
- Do not grind, punch or change its shape in any way.

Note

- In order to prevent loss, please take good care of your keys and make a copy immediately if you are worried about losing them.

Gauges, controls, and other features

Ignition switch, engine flame-out switch

Ignition switch

1. When parking, please set the ignition switch to the '⊗' or '🔒' position to avoid unnecessary loss of the battery, which will cause excessive battery power loss and will cause it to not start.
2. While riding, do not rotate the key.

Engine flame-out switch

Do not use the engine kill switch except in an emergency. Doing so while riding can cause the engine to stop suddenly, making the ride unsafe.

Odometer, Chronometer (subtotal mileage)

Odometer

When the reading exceeds the 999999, the display locks at the 999999.

Chronometer

When the meter's reading exceeds 999.9, it is automatically cleared.

Maintenance of motorcycles

Frequent cleaning and polishing ensure that the motorcycle lasts for a long time, and a clean motorcycle is more likely to detect potential failures, especially noting that the anti-icing seawater and salt spilled on the road will accelerate the formation of corrosion, and it is important to thoroughly clean the motorcycle after driving along the coast or on the above-mentioned treated roads.

Clean

Wait for the engine, muffler, brakes, and other hot parts to cool before cleaning.

1. Rinse the motorcycle thoroughly with low-pressure hose water to remove dirt.
2. If necessary, use a sponge or soft towel dipped in flexible detergent to remove the dirt on it.
3. Rinse the motorcycle thoroughly with enough clean water and dry it with a clean, soft cloth.
4. After drying the motorcycle, lubricate the moving parts to make sure that no lube oil spills on the brakes or tires; Oil-contaminated brake discs, brake pads, brake drums, and brake shoes will have a greatly reduced braking performance and may cause accidents.
5. After washing and drying the motorcycle, lubricate the drive chain immediately.
6. Waxing can prevent corrosion. Avoid products containing strong stain removers or chemical solvents that can damage metal, paint, and plastic parts of motorcycles; Do not wax tires and brakes.

If your motorcycle has parts with matte paint, do not wax on these matte paint.

Cleaning precautions

- Do not use high-pressure water guns:
 - ▶ High-pressure water cannons can damage moving and electrical parts beyond repair.
 - ▶ Moisture from the air intake may be drawn into the throttle body or into the air filter.
- Do not use water to flush the muffler directly:
 - ▶ Water ingress in the muffler can cause the muffler to fail to start and the muffler to rust.
- Drying brake:
 - ▶ Water will reduce braking performance, after cleaning, you should intermittently use the brake at low speed, repeatedly press the brake pedal, and use the heat generated by brake friction to dry the water until the braking efficiency is restored.
- Do not rinse directly under the seat with water:
 - ▶ Water getting into the seat compartment can damage your documents and other items.
- Do not rinse the area near the headlamp directly with water:
 - ▶ After washing or when cycling in the rain, the internal lens of the headlamp may temporarily fog up, which will not affect the function of the headlamp. However, if you notice a large amount of water or ice accumulating in the lens, please refer it to a Kove repair shop for inspection.
- Do not wax and polish matte paint:
 - ▶ Clean the matte paint finish with plenty of water and mild detergent and dry it with a soft, clean cloth.

Aluminum components

Aluminum can be corroded after contact with dirt, mud or salt, clean aluminum parts regularly and follow these guidelines to prevent scratches:

- Do not use stiff brushes, steel wool balls or other abrasive cleaning products.
- Do not drive or scratch on the curb.

Panel

Follow these guidelines to prevent scratches and damage:

- Wash gently with a sponge and enough water.
- Clean with diluted detergent and wash thoroughly with plenty of water to remove stubborn dirt.
- Please avoid contact with corrosive liquids such as gasoline and brake fluid on the instrument panel and lampshade.

Moving parts

Anti-rust oil can effectively prevent mechanical rust, when motorcycle washing or heavy rain, you can apply anti-rust oil on the moving parts of the motorcycle, such as engine output shaft, clutch cables, side brackets, shift levers, etc.

Muffler

The muffler is stainless steel, but it can also be dirty due to mud or dust, which can be removed with a wet sponge dipped in detergent, then carefully rinsed with clean water and dried with suede or a soft towel. If necessary, burn marks can be removed with commercially available compounds with a fine texture and then rinsed in the same way as mud and dust.

If the muffler has been painted, use a neutral stain remover to clean the exhaust pipe and muffler paint, and if you are unsure whether the muffler has been painted, contact the Kove Repair Shop.

Note

- Although the muffler is stainless steel, it can also rust. Once found, remove all traces and dirt immediately.

Storage of motorcycles

If you leave your motorcycle outdoors, you should consider using a motorcycle full body shield. If you don't ride for a long time, follow these guidelines:

- Wash the motorcycle and wax all paint surfaces (except matte paint) and apply anti-rust oil to all chrome parts.
- Lubricate the drive chain.
- Place the motorcycle on the maintenance stand and raise it with a wooden block so that both tires are off the ground at the same time.
- After it rains, remove the body cover and let the motorcycle dry.
- Remove the battery to prevent discharge.

Fully charge the battery and place it in a cool and ventilated place, and if you leave the battery in place, disconnect the negative terminal to prevent discharging. Before reusing the stored motorcycle, check all items required on the maintenance cycle.

Transportation of motorcycles

If your motorcycle needs to be transported, a motorcycle trailer, a flatbed truck loaded with ramps or lifting platforms should be used, and motorcycle straps should be used. Never try to drag a motorcycle with its wheels on the ground.

Note

- Towing a motorcycle can seriously damage the transmission.

You and environment

Owning and riding a motorcycle is enjoyable, but you have to do your duty to protect the environment.

Choose the right detergent

Use biodegradable stain removers when washing motorcycles and avoid sprays containing chlorofluorocarbons (CFCs) as it destroys the protective layer of the atmosphere (the ozone layer).

Waste recycling

Separate motor oil and other toxic wastes in approved containers and take them to a recycling center, call your local National Public Affairs or Environmental Services office to find a recycling center in your area, and instructions on how to dispose of non-recyclable waste, do not dump used engine oil in trash cans, sewers or on the ground because used motor oil, gasoline, coolants and cleaning solvents contain Toxic substances that can harm cleaners, pollute drinking water, lakes, rivers and the sea.

Frame number, engine number, nameplate

The frame number and engine number are required for motorcycle registration, which are unique and used to identify your motorcycle and may be required when ordering replacement parts, please keep these numbers on record and keep them in a safe place.

Frame number

The frame number is engraved on the right side of the frame riser



Engine number

The engine number is engraved on the left side of the engine block



Nameplate

The nameplate is affixed to the front of the diagonal tube in front of the frame



Catalytic converters

The motorcycle is equipped with a three-way catalytic converter. The catalytic converter contains precious metals as high-temperature chemical reaction catalysts to convert hydrocarbons (HC), carbon monoxide (CO) and nitrogen oxides (NOx) in the exhaust gas into a regulatory-compliant mixture.

A faulty catalytic converter can pollute the air and degrade your engine's performance, so be sure to use original Kove parts when replacing.

Follow these guidelines to protect your motorcycle's catalytic converter:

- Use only unleaded gasoline, which can damage the catalytic converter.
- Keep the engine in good working order.
- If the engine does not catch fire, backfire, stall or other bad running, please stop riding immediately, turn off the engine, and hand over the motorcycle to the Kove Repair Shop for maintenance.

Technical Specs

Motorcycle related specs	8
Torque specs	8
Frame tightening torque	8

Motorcycle related specs-1

Model	KY450	Engine model	Z194YMQ
Length (mm)	2190	Bore(mm)× stroke(mm)	94.5×64.0
Width (mm)	805	Compression ratio	12.5:1
Height (mm)	1420	Max.net power (KW/r/min)	31.0/8500
Wheelbase (mm)	1475	Max. torque (N·m/r/min)	35.0/6500
Curb weight (kg)	155	Idle speed (r/min)	2000±150
Preload (kg)	75	Cylinder working volume (ml)	449
Front tire	90/90-21 M/C 54R	Spark plug	CR8E
Rear tire	140/80-18 M/C 70R	Spark plug gap (mm)	0.7-0.8
Max. speed (km/h)	170	Valve clearance (mm)	Intake valve: 0.10-0.15
			Exhaust valve: 0.15-0.20

Motorcycle related specs-2

Lubricating oil capacity(L)	1.8 (Note: 1.6L when replacing oil fine filter, 1.8L when disassembling and reassembling engine)	Main fuse	30A
Gasoline capacity (L)	14	Headlight	LED
Primary gear ratio	2.286	Front position light	LED
First gear	2.357	Rear position light/brake light	LED
Second gear	1.824	Front turn signal	LED
Third gear	1.474	Rear turn signal	LED
Fourth gear	1.181	Neutral light	LED
Fifth gear	1.000	Rear license plate light	LED
Sixth gear	0.846	Turn indicator	LED
Final gear ratio	3.769	Gauge indicator	LED
Battery	12V 4Ah (Lithium battery)	Ignition method	ECU control ignition

Torque Specs

Fastener type	Torque (N·m)	Fastener type	Torque (N·m)
5mm bolts and nuts	6	6mm screws	8
6mm bolts and nuts	12	6mm flange bolts(8mm head:small flange)	10
8mm bolts and nuts	22	6mm flange bolts(8mm head:big flange)	12
10mm bolts and nuts	60	6mm flange bolts(10mm head) and nuts	12
12mm bolts and nuts	80	8mm bolts and nuts	22
5mm screws	5	/	/

Note

- In addition to the specified torque, this vehicle adopts the standard torque values in the table above.

Frame tightening torque

Assembly position	Thread diameter (mm)	Torque (N·m)	Remark
Self-tapping nail for connecting front brake fluid line pressure plate and the front shock absorber trim piece	ST4.8	1	
Self-tapping nails for rear fender mud liner and rear fender rear section connection	ST4.8	1	
Self-tapping nails for OBD and electrical bracket connection	M4.2	1	
Screws for rear fender rear section lower cover and tailpiece attachment	M5	3	
Screws for rear fender rear section lower cover and rear fender rear section	M5	3	
Socket countersunk head screws for fuel tank fitting mounting plate and left and right rear fuel tank connections	M5	5	
Socket countersunk head screw for oil level sensor mounting plate and left fuel tank	M5	5	
Crossed recessed tapping screws for oil pump and oil tank	M5	5	
Crossed recessed tapping screws for meter attachment and cowl bracket	M5	4	
Crossed recessed tapping screws for position light and tailgate	M5	4	
Crossed recessed tapping screws for rear light and tailgate connection	M5	4	
Internal hex bolt for rear tailgate and rear fuel tank	M5	4	
Internal hex screw for front windshield and fuel tank front trim piece	M5	4	
Hex socket head cap screws for front gear ring and front wheel rim	M5	5	Thread glue
Crossed screws for rear brake hose clamp and flat fork connection	M5	5	
Internal hex bolts for rear harness wire clip and rear fuel tank	M5	4	
Hex socket head cap screws for rear gear ring and rear wheel rim	M5	5	Thread glue
Crossed recessed tapping screws for fuel filter mounting bracket and fuel tank	M5	4	

Assembly position	Thread diameter (mm)	Torque (N·m)	Remark
Hex screws for headlight bracket lever and headlight bracket	M5	4	
Crossed recessed tapping screws for attachment of side lean sensor and electrical mounting bracket	M5	5	
Crossed recessed tapping screws for ECU and rear fuel tank connection	M5	4	
Hex countersunk head screws for seat cushion locking seat and rear fuel tank	M6	8	
Hex socket pan head step screw for front shock trim and front shock absorber attachment	M6	5	
Crossed recessed tapping screws for chain guard and flat fork	M6	8	
Hex socket flower pan head screws for rear brake master cylinder and frame	M6	8	
Internal hex socket countersunk head screws for rear fuel tank protection plate to rear fuel tank connection	M6	8	
Internal hex bolts for electrical bracket and tank reinforcement bracket	M6	12	
Internal hex bolts for electrical bracket and rear fuel tank	M6	8	
Internal hex step screws for headlight trim and headlight mounting brackets	M6	8	
Internal hex pan head step screws for headlight trim and headlight mounting brackets	M6	8	
Internal hex pan head screws for side bracket flameout switch and side bracket connection	M6	8	
Internal hex socket head cap screws for left and right front fuel tanks to tank mounting brackets	M8	22	
Hex socket head cap screws in front of the left and right front fuel tanks for attachment to the frame	M8	22	
Hexagon socket head cap screws for ignition lock to upper coupling plate	M8	22	
Internal hex bolts for left and right headcover bracket	M5	5	
Hex bolts for oil-cooled lattice deletion and lower shield connection	M5	5	

Assembly position	Thread diameter (mm)	Torque (N·m)	Remark
Internal hex bolts for radiator grid deletion and radiator	M5	5	
Internal hex bolts for shield mounting brackets and left and right front fuel tanks	M5	5	
Internal hex bolt for rear brake pedal and rear brake rocker arm	M5	3	Thread glue
Inner hex bolts for headlight and headlight mounting bracket	M5	5	
Internal hex bolts for side bracket hitch bracket and rear fuel tank	M5	5	
Internal hex bolts for front brake master cylinder and steering handle	M6	10	
Internal hex bolts for oil cooler and frame connection	M6	12	
Hex bolts for small sprocket cover and engine connection	M6	8	
Internal hex bolts for muffler mounting bracket and rear fuel tank	M6	10	
Internal hex bolts for lower guard and frame	M6	12	
Inner hex bolts for head cover bracket and headlight bracket	M6	12	
Internal hex bolts connecting the regulator to the electrical bracket	M6	10	
Internal hex bolts for radiator and frame connection	M6	12	
Internal hex bolts for front brake fluid hose clamp and lower connecting plate	M6	10	
Internal hex bolts for the front disc brake disk and the front hub	M6	12	Thread glue
Internal hex bolts for front fender and lower coupling plate connection	M6	8	
Internal hex bolt for front ABS sensor mounting connection	M6	10	
Internal hex flange face bolt for injector cap and throttle	M6	8	
Hex bolts for clutch handle mounting	M6	10	
Internal hex bolts for horn and frame connection	M6	12	

Assembly position	Thread diameter (mm)	Torque (N·m)	Remark
Internal hex bolts for air filter and frame	M6	12	
Internal hex bolts for rear fuel tank lower mounting bracket and rear fuel tank connection	M6	10	
Internal hex bolts for rear fuel tank reinforcement bracket and rear fuel tank connection	M6	10	
Internal hex bolt for rear brake caliper trim and rear brake caliper	M6	10	
Internal hex bolts for rear disc brake disk and rim	M6	12	Thread glue
Hex socket pan head step screws for rear water proof and rear fuel tank	M6	10	
Hex flange face bolt for rear ABS sensor bracket and rear caliper bracket	M6	12	
Internal hex bolt for rear ABS sensor and bracket	M6	8	
Internal hex bolts for chain guide and flat fork	M6	10	
Inner hex bolts for headlight bracket and headlight module	M6	12	
Internal hex bolts for shifter and engine	M6	12	
Internal hex bolts for ABS and ABS bracket	M6	12	
Internal hex bolts for left and right head cover bracket and frame	M8	22	Thread glue
Hex bolts for left and right chain adjustment	M8	10	
Internal hex bolts for muffler and frame	M8	22	
Internal hex bolts for the rear section of the muffler and the bracket	M8	22	
Internal hex bolts for lower connecting plate and shock absorber	M8	22	
Tail pack mounting bolts for rear tailgate, rear fender rear section and rear fuel tank	M8	22	
Internal hex bolts for upper suspension plate and frame	M8	35	
Hex bolts for upper connecting plate and shock absorber	M8	22	

Assembly position	Thread diameter (mm)	Torque (N·m)	Remark
Hex bolts with inner hexagonal pattern for connection of upper and lower holders	M8	22	
Internal hex bolt for front brake caliper and front shock absorber	M8	32	Thread glue
Internal hex bolts for front shock absorber and front axle	M8	22	
Internal hex bolts for front shock absorber and front axle	M8	22	Thread glue and grease
Rear tank mounting bolts for rear tank and frame	M8	22	Thread glue
Hex bolts for rear section of rear fender and rear fuel tank	M8	22	
Internal hex bolts for engine front suspension plate and fuel tank mounting bracket	M8	15	
Internal hex bolts for engine front suspension plate and frame	M8	22	
Guide sprocket bolts connecting the guide sprocket to the U-shaped cradle	M8	22	
Hex bolt for the oil level sensor and the mounting plate	M10	22	
Internal hex bolts for connection of the lower bay and the upper connecting plate	M10	35	Thread glue
Flat head bolts for rear shock and triangle rocker	M10	44	
Internal hex bolts for rear shock absorber and frame	M10	44	
Hex bolts for engine lower suspension and engine	M10	54	
Hex bolts for engine upper suspension and bracket	M10	60	
Hex bolts for engine front suspension and engine	M10	54	
Side bracket special bolts for attaching side bracket to frame	M10	2	
Hex bolts for U-shaped rocker and frame	M10	60	
Flat head bolts for the triangular rocker and the flat forks	M12	60	
Flat head bolts for U-shaped rockers and triangular rockers	M12	60	
Hex bolts for the upper connecting plate and the steering column	M14	80	Grease

Assembly position	Thread diameter (mm)	Torque (N·m)	Remark
Hex nut for rear license plate light and rear section of rear fender	M5	5	
Hex self-locking nut for muffler rear section and bracket	M8	22	
Hex self-locking nut for engine front suspension plate and frame	M8	26	
Hex flange face self-locking nut for guide wheel to guide wheel bolt connection	M8	22	
Hex self-locking nut for rear shock and delta rocker	M10	44	
Hex self-locking nut for engine lower suspension connection and engine	M10	54	
Hex self-locking nut for engine front suspension and engine	M10	54	
Front axle nut	M16	88	
Flat fork axle nut	M16	88	
Rear axle nut	M22	128	
4-slot adjusting nut for steering column locking connection	M25	The first level of 40N·m, the second level of loose two turns to adjust the nut after the nut tightened to 10N·m, the third level of fixed direction does not move to loosen 1/4 turn	